

bonaVITA™

BV3825B05

0.5 L Travel Kettle

Customer assistant line:

USA 1-855- 664 -1252



Features:

Small size

Easy Grip handle for excellent pour control

Brushed Stainless finish

900 W

FOR HOUSEHOLD USE ONLY

READ THE MANUAL BEFORE USE AND SAVE FOR FUTURE REFERENCE

1 year limited warranty

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- **Read all instructions.**
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock and injury to persons, do not immerse cord, plugs, base or kettle in water or other liquid.
- Never leave the appliance unattended when in use. Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, no water in kettle, filling water, moving kettle and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Call our toll-free Customer Assistance Number for examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Electric kettle must be operated on a flat surface. Do not place on or near a hot gas or electric burner, or in a heated oven, or on the top of other electric appliances.
- Do not use appliance for other than intended use.
- To avoid circuit overload, do not operate another high wattage appliance on the same circuit.
- Be aware of steam being emitted from spout or lid especially during refilling. Do not remove lid during boiling cycle.
- Do not use the kettle to heat anything other than water. Do not fill above the "max" indication. If the kettle is overfilled, boiling water may be ejected. The kettle is only to be used with the base unit provided.
- Do not insert any object into slots or holes of the kettle.
- Scalding may occur if the lid is removed during water heating.
- This appliance is for **HOUSEHOLD USE ONLY**.

SAVE THESE INSTRUCTIONS

ADDITIONAL SAFEGUARDS

DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

EXTENSION CORDS


A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. If a longer detachable power-supply cord or extension cord is used,

- 1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, and
- 2) The extension cord should be a grounding-type 3-wire cord, and
- 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally (especially by children).


GROUNDING INSTRUCTIONS

This appliance must be grounded while in use.


CAUTION: To ensure continued protection against risk of electric shock, connect to properly ground outlets only.








Part



1. Lid
2. On/Off switch
3. Body
4. Power indicator
5. Power cord with plugs
6. Travel cup (2 pieces)



ILLUSTRATOR



OPERATION

Before plugging the kettle into the wall outlet, check that the electrical circuit is not overloaded with other appliances.

Preparing the Kettle for First time Use:

- Fill the kettle to Max fill line with cold water to boil and empty.
- Let the appliance cool down 1 minute
- Repeat boiling and rinse at least 2 times before using.

Setting up the Kettle:

- Take off the lid (1). Fill the kettle with cold water. Do not fill over the max marking. See the water level inside of the kettle for adding the desired amount of water.(ill.A)
- Close the lid firmly.
- Place the kettle on a flat, even and steady surface.
- Plug the power cord plug (5) into a 120V 60 Hz wall socket.(ill. B)
- Turn on the O/I switch (2), the power indicator (4) will illuminate. When finished boiling, the switch will turn off automatically. During the boiling process, press the O/I switch anytime to cancel the boiling. (ill. C)
- Pour the hot water into a vessel slowly. (ill. D)

Note: Unplug kettle when not in use.

WARNING: The appliance is very hot during use. Do not touch kettle surface. Danger of burns! (ill.E)

WARNING: Never leave the kettle unattended while boiling water. Especially if there are children nearby.

WARNING: Do not open the lid while boiling water.

WARNING: Do not immerse the power cord with plug (5) or the kettle in water or any liquids. This may cause electric shock or damage the appliance.(ill. F)

WARNING: Be careful when handling hot water. Danger of scalding!

CLEANING

Clean the kettle regularly. This appliance contains no user serviceable parts and requires little maintenance. Leave any servicing or repairs to qualified personnel.

- Clean the outside of the kettle with a damp soft cloth.
- Clean the inside of the kettle with dish soap and rinse thoroughly with water.
- Do not use abrasive cleansers.
- After cleaning dry the kettle thoroughly.
- Do not put the kettle in dishwasher.

WARNING: Never immerse the kettle in water or other liquids.





DECALCIFYING

When mineral scale builds up in your kettle, it can affect temperature consistency and slow down boil time. If Not descaled regularly, the kettle can stop working accurately. To ensure optimum performance, Bonavita recommends descaling the kettle when mineral build-up is visible inside the kettle.

Note: Vinegar may not effectively descale the kettle and can be difficult to thoroughly rinse. Vinegar may also leave behind an odor that could affect future uses. Bonavita recommends using Dezcal Descaler.

How to use Decal Descaler:

1. Fill the kettle with warm water.
2. Add one packet of Dezcal to kettle.
3. Bring solution to boil.
4. Let vessel cool for 15 mins, then discard solution.
5. Rinse thoroughly with fresh water.



STORAGE

Clean and dry all parts before storing. Store the kettle in its box or in a clean, dry place. Never wrap the power cord around the kettle.

TECHNICAL DATA

Rated voltage:	120 V 60 Hz
Rated current:	7.5 A
Rated power input:	900 W
Capacity:	max. 16.9 oz (0.5 L)

LIMITED WARRANTY

1 year limited warranty from the date of original purchase.

1. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. The product must be purchased at an authorized retailer for the warranty to be valid.
2. Defects that occurred due to improper connection, improper handling, or repair attempts by non-authorized persons are not covered by the warranty. The same applies for failure to comply with the use of consumables (e.g. cleaning and decalcifying agents or water filters) that do not correspond to the original specifications.
3. Routine wear parts (e.g. Seals and valves, permanent filter) and fragile parts like glass are excluded from the warranty.
4. Damages which are not under responsibility of the manufacturer are not covered by the warranty. This is valid, especially for claims arising from improper use (e.g. operation with wrong type of current or voltage).
5. The guarantee becomes void if repairs are carried out by third parties, who are not authorized by the manufacturer to do so and/or if spare parts are used other than the original ones.
6. Failure to comply with any important safeguards listed in section 1 will void limited warranty.
7. This appliance was designed for Household use only. It is not dedicated for other use.

To make a warranty claim, do not return this appliance to the store. Please email customerservice@bona-vita.biz or call 1-855-664-1252. For faster service, locate the model, type and series numbers on your appliance and have available for the call or website visit.